



Flying Chair

The flying chair is used to inspect and work on the outside areas of aircraft, areas not normally accessible.

With an overhead crane connected the flying chair can be used for example on the upper fuselage of the aircraft and other inaccessible areas of the docking systems.



CUSTOMER ADVANTAGES

- access to all areas on aircraft
- generally applicable
- convenient

Technical data

Dimensions	Length	mm	840
	Width	mm	870
	Height	mm	1480
Weight		kg	45
Max. load			1 person with tools max. 1000 N
Max. speed of the crane		m/s	0.5

Contact

Lufthansa LEOS GmbH
Sales, Marketing & Product Development
Lufthansa-Basis
D-60546 Frankfurt/Main
Germany

Hotline: +49-69-696-8222

Fax: +49-69-696-93888

Email: sales@lufthansa-leos.com

www.lufthansa-leos.com